

パワーチャック用ハードジョー把握範囲一覧 (ジョー型式をクリックすると各ジョーの寸法図を表示します。)

チャック	ジョー	外径把握								内径把握				ハードジョー外径把握可動範囲
		A1	Fig.NO.	A2	Fig.NO.	A3	Fig.NO.	A4	Fig.NO.	B1	Fig.NO.	B2	Fig.NO.	ハードジョー内径把握可動範囲
BR05	<a href="#">HB04N1</a>	3-32	9	---	---	78-107	11	---	---	54-81	9	---	--	3-59,78-134
		31-59	10	---	---	106-134	12	---	---	80-108	10	---	--	54-108
BR06	<a href="#">HB06A1</a>	20-45	9	---	---	101-126	11	---	---	78-103	9	---	--	20-45,60-85,101-126,141-166
		60-85	10	---	---	141-166	12	---	---	118-143	10	---	--	78-103,118-143
BR06	<a href="#">HB06B1</a>	16-41	5	33-58	5	23-48	7	49-74	7	131-156	5	---	--	16-114
		56-81	6	73-98	6	63-88	8	89-114	8	---	--	---	--	131-156
BR08	<a href="#">HB08B1</a>	10-37	5	34-61	5	24-51	7	58-85	7	166-193	5	---	--	10-135
		60-87	6	84-111	6	74-101	8	108-135	8	---	--	---	--	166-193
BR08	<a href="#">HB08N1</a>	32-59	1	10-37	3	82-109	3	110-137	3	113-140	1	141-169	1	10-59,60-109,110-159,160-187
		82-109	2	60-87	4	132-159	4	160-187	4	163-190	2	---	--	113-140,141-190
BR10	<a href="#">HB10AA1</a>	15-55	1	34-80	3	120-166	3	154-200	3	106-145	1	140-179	1	15-226
		69-115	2	94-140	4	180-226	4	---	--	160-205	2	194-239	2	106-239
BR12	<a href="#">HB12N1</a>	50-120	9	---	--	181-251	11	---	---	141-211	9	---	---	50-180,181-311
		110-180	10	---	---	241-311	12	---	---	201-271	10	---	---	141-271

