

※Click the jaw model number to see dimensions.

| Chuck model | Chuck size | Two piece type | | Monoblock type | |
|-----------------------------|------------|---------------------------------------|------------------------|---|---|
| | | Soft jaw | Hard jaw | Hard jaw | |
| SC-3F | 3 | SBS03 | — | SC-3 internal jaw | SC-3 external jaw |
| SC-4F | 4 | SBS04 | — | SC-4 internal jaw | SC-4 external jaw |
| SC-5F | 5 | SBS05 | — | SC-5 internal jaw | SC-5 external jaw |
| JN06T / JN06RA5 | 6 | SBS06 | HBS06C | — | — |
| JN07T / JN07RA5 / JN08RA6 | 7or8 | SBS07 | HBS07C | — | — |
| JN09T / JN09RA6 | 9 | SBS09 | HBS09C | — | — |
| JN10T / JN10RA6 / JN10RA8 | 10 | SBS10 | HBS10C | — | — |
| JN12T / JN12RA6 / JN12RA8 | 12 | SBS12 | HBS12C | — | — |
| JN06 | 6 | — | — | JN06 internal jaw | JN06 external jaw |
| JN07 | 7 | — | — | JN07 internal jaw | JN07 external jaw |
| JN09 | 9 | — | — | JN09 internal jaw | JN09 external jaw |
| JN10 | 10 | — | — | JN10 internal jaw | JN10 external jaw |
| JN12 | 12 | — | — | JN12 internal jaw | JN12 external jaw |
| SC-14 | 14 | — | — | SC-14 internal jaw | SC-14 external jaw |
| SC-16 | 16 | — | — | SC-16 internal jaw | SC-16 external jaw |
| SC-4S (Stationary type) | 4 | SBS04S | — | — | — |
| SC-5S (Stationary type) | 5 | SBS05S | — | — | — |
| JS07 (4-jaw, monoblock jaw) | 7 | — | — | JS07 internal jaw <small>(note 3)</small> | JS07 external jaw <small>(note 4)</small> |
| JS09 (4-jaw, monoblock jaw) | 9 | — | — | JS09 internal jaw <small>(note 5)</small> | JS09 external jaw <small>(note 6)</small> |
| JT07 (2-jaw, two piece jaw) | 7 | JT07 soft jaw <small>(note 1)</small> | — | — | — |
| JT09 (2-jaw, two piece jaw) | 9 | JT09 soft jaw <small>(note 2)</small> | — | — | — |

※(note 1) Soft jaws for JN07 have the same dimensions as SBS07.

※(note 2) Soft jaws for JN09 have the same dimensions as SBS09.

※(note 3)(note 4) Hard jaws for JS07 have the same dimensions as JN07.

※(note 5)(note 6) Hard jaws for JS09 have the same dimensions as JN09.